




CI-803C



Loosen the screw on bottom then can be turn whole around and appear up and down.